




M6 TTL

Bedienungsanleitung / Instruction





The CE-Labeling on our products certifies that these products meet the basic requirements of current EU guidelines

Warning Notice

Modern electronic equipment is sensitive to electrostatic discharges.

People can easily pick up electrostatic charges of a few 10 000 volts, for instance when they walk over a synthetic carpet. These electrostatic charges can be discharged by touching their LEICA, especially if the camera is lying on a conductive surface.

If this discharge only involves the camera body, it is completely harmless to the camera's electronics. In spite of the additional built-in protective circuitry of LEICA cameras, the external electrical contacts, such as those for the winder and the data back, should not be touched for safety precautions.

Should you wish to clean the contacts please **do not use** (synthetic!) **optic microfibre cloths**, but rather a cotton or linen cloth. Any possible electrostatic charges can be fully discharged by deliberately touching radiators or water pipes (conductive, earthbound objects).

Please avoid soiling and oxidizing the electrical contacts by assuring that your LEICA is stored in a dry place with the protective covers in place.

52

Leica Akademie

Leica not only manufactures high-performance products for everything from observation to reproduction: it offers a special service in the form of the Leica Akademie. For many years, this internationally famous facility has taught photographic expertise in practical seminars and training courses. It meets the needs of keen photographers, both beginners and advanced students, for special training in demanding areas of 35 mm photography, projection, and enlargement.

Up-to-date, well-equipped seminar rooms are available at our Solms headquarters and at the nearby "Gut Altenberg" for these courses, which are held by experienced instructors, the content of which ranges from general photography to specialised fields of interest. They provide a wealth of practical suggestions, help, and advice. Further information and details of seminars are available from:

Leica Camera AG
Leica Akademie
Oskar Barnack Str. 11
D- 35606 Solms
Tel: 06442 208 421
Fax: 06442 208 425
e-mail: la@leica-camera.com

Dear Customer,

Congratulations on your decision to purchase the LEICA M6 TTL. You have chosen an excellent and unique rangefinder camera.

We wish you many years of pleasure and successful photography with your camera.

We recommend that you read these instructions first in order to derive full benefit from the photographic possibilities offered by your new camera.

Leica Service Center

Internet

<http://www.leica-camera.com>


Information service

Should you have any technical questions regarding the use of Leica products, please contact the Leica information service in writing or by phone:

Leica Camera AG
Information service
Oskar Barnack Str. 11
D- 35606 Solms
Tel: 06442 208 111
Fax: 06442 208 339
e-mail: info@leica-camera.com

53

Fitting the carrying strap



54



Power supply

The LEICA M6 TTL requires two 1.5 volt silver oxide button cells or one 3 volt lithium cell for the exposure meter and to trigger connected flash units.

If the camera is not in use for longer periods of time or if you wish to keep a battery with you as replacement, lithium cells are particularly suitable, as they can be stored for several years with no loss of energy.

Batteries

Silver oxide button cells	Lithium cells
Duracell D 357 (10 L 14)	Duracell DL 1/3 N
Everready EPX 76	Kodak K 58 L
Kodak KS 76	Philips CR 1/3 N
Maxell SR 44	Ucar 2 L 76
National SR 44	Varta CR 1/3 N
Panasonic SR 44	
Philips 357	
Ray-o-vac 357	
Sony SR 44	
Ucar EPX 76	
Varta V 76 PX	

Loading and replacing the batteries

1. Unscrew the battery compartment cover (1).
2. Wipe any oxidation residue off the cells using a clean cloth.
3. Insert the cells into the holder in the battery compartment cover. Pay attention to the polarity.
4. Now screw the cover together with the cells back into the camera.
5. To remove the batteries, follow the same procedure in reverse.

A set of fresh batteries has a life of approximately 8 hours with the exposure meter switched on continuously. Assuming 10-second measurements in normal use, one set of batteries therefore supplies sufficient energy for approx. 2900 exposures, i.e. 80 films of 36 exposures each.

55

Automatic battery check

If the red LED is flickering, i.e. its brightness fluctuates, the batteries should be replaced. If the cells are unable to supply the minimum operating voltage, the LED display disappears.


Note: The electrical circuit can be broken by oxidation of the battery surfaces; this will also cause the LEDs to go out. In this case, remove the batteries and clean the battery terminals, camera contacts and battery compartment cover with a clean cloth.

Important:

- Always replace batteries in full sets. Do not mix batteries of different make or type.
- Keep battery contacts clean.
- Do not incinerate, recharge, open, dismantle or heat the batteries.
- Remove exhausted batteries as soon as possible. Do not dispose of used batteries in normal garbage as they contain environmentally harmful substances.

- In order to ensure proper battery recycling, take the batteries to a recycling point.
- If the camera is not to be used for longer periods, remove the batteries.
- Store batteries in a cool and dry place.

56



Quick-wind lever

The quick-wind lever (8) is used to advance the film, to cock the shutter and to automatically advance the frame counter. For rapid sequences, the user can put the lever into a "ready position".

Shutter release button

The shutter release button (7) should be pressed softly (not jerkily) until it clicks and the shutter is opened. The shutter release has a threaded socket to accept standard cable releases.

Shutter speed dial

The size and location of the shutter speed dial of the LEICA M6 TTL are ergonomically perfect: on the one hand, the dial is extremely easy to use and can also be operated with the camera held to the eye. On the other hand it is well protected to prevent it from being switched on or the settings changed accidentally. In addition, its direction of rotation (like that of the aperture ring on the lenses) corresponds to the exposure meter displays in the viewfinder; if the left-hand triangular LED is flashing for example, turning the wheel in the direction of the arrow, i.e. to the right, will lead to the slower shutter speed required.

The shutter speed dial (10) of the LEICA M6 TTL is used to select the shutter speeds - from 1/1000s to 1 s - and also the synchronising speed "Z" for flash operation (1/50s) and "B" for long exposures.

57

When the dial is set to "B", the shutter remains open until the shutter release button is released.

The "OFF" position is located between "B" and the end of the scale. When the dial is turned to this position, the exposure meter is switched off.

The speed selector dial engages positively at all engraved speeds. Intermediate speeds cannot be selected.

For details on correct exposure, see the "Exposure metering" section on page 74.




Loading the film

Always start by making sure that there is no film in the camera by turning the rewind crank (13) gently in the direction of the arrow. Any resistance indicates that a film is already loaded; see rewinding instructions on page 61. Begin by actuating the wind lever and pressing the release button. Hold the camera in your left hand with the base plate pointing upwards.

Opening the camera

1. Raise the latch (20) on the base plate (19).
2. Turn the latch to the left.
3. Remove the base plate.
4. Fold the back (23) out towards the rear.

58



Note: With the camera back open, three gold-plated electrical contacts (29) are visible on the back and in the camera housing. These contacts are corrosion-free, and relatively insensitive to dirt and dust. Special care of these contacts is not necessary.

When loading a new film, however, ensure nevertheless that the contacts are kept clean and dry.

Inserting the film

5. Hold the film cartridge in the right hand and insert it about half-way into the empty chamber.
6. Take the film leader and pull it into the take-up chamber spool (28), as shown in the diagram (27) of the camera housing.
7. Using your fingers push the cartridge and the film leader carefully into the camera.

Note: The end of the film must be tapered, as is the case with made-up films. Under ordinary conditions it does not matter if the film end projects through the three-post assembly. In extremely cold, dry weather, however, the end may break off, and the drawing should then be followed exactly.

Important

Do not check correct loading when the camera is open. The base plate is designed such that it guides the film into the correct position when attached to the camera.

59



Closing the camera

18. Replace the camera back.
19. Hook the base plate over the external mounting post on the camera body (25).
10. Fold the base plate back into its normal position, ensuring that the camera back is in full contact so that the base plate envelops it.
11. Lock the back using the base plate catch.

Transport of the film to the first frame

12. Advance the film to the next frame by means of the quick-wind lever, and release the shutter.
13. Gently pull the film taut by turning the rewind crank (13) in the direction of the ar-

- row. The film is properly transported when the rewind crank turns backwards when the quick-wind lever is operated again.
14. Finally, press the shutter release button again and cock the shutter for the third time. The frame counter (6) now reads 1 and the camera is ready to shoot.

Setting the film speed


The dial for setting the exposure meter to the film speed (24) can be used to set values from ISO 6/9° to ISO 6400/39° (ASA 6/9 DIN to ASA 6400/39 DIN; the ISO designation is that generally used internationally). To set the film speed:

1. Press the centre of the dial down and turn it until the two triangles are aligned opposite the desired film speeds (DIN above, ASA below).
2. When released, the disc will engage and spring back flush with the surrounding ring if it has been set properly.

60

The following settings are possible:

Scale	Film speed ISO (ASA/DIN)	Scale	Film speed ISO (ASA/DIN)
6/9°	6/9°	200/24°	200/24°
-	8/10°	-	250/25°
-	10/11°	-	320/26°
12/12°	12/12°	400/27°	400/27°
-	16/13°	-	500/28°
-	20/14°	-	640/29°
25/15°	25/15°	800/30°	800/30°
-	32/16°	-	1000/31°
-	40/17°	-	1250/32°
50/18°	50/18°	1600/33°	1600/33°
-	64/19°	-	2000/34°
-	80/20°	-	2500/35°
100/21°	100/21°	3200/36°	3200/36°
-	125/22°	-	4000/37°
-	160/23°	-	5000/38°
		6400/39°	6400/39°



Film rewind and removal

When the last frame has been exposed, the quick-wind lever can no longer be operated. Before the film can be removed, it must be wound back into the cartridge.

1. Turn rewind lever (5) to "R".
2. Swing out the lever for the rewind crank.
3. Turn the lever clockwise (in the direction of the arrow) until the film is freed from the take-up spool; slight resistance will be felt at this point.

61

4. Now open the base plate.
5. Open the camera back.
6. Remove the film cartridge.

When the film is not fixed to the cartridge core, for example when bulk film is used, it may become separated from the core if the advance lever is operated forcefully after the last frame has been exposed. In this case, proceed as follows:

1. Remove the base plate of the camera in a completely dark room.
2. Hold the camera with the base plate open and facing downwards.
3. Slowly operate the quick-wind lever several times until the film protrudes far enough to be grasped and pulled out. If necessary, gently hit the camera against the palm of your hand.



Fitting the lens to the camera

1. Hold the lens by the fixed ring (15).
2. Align the red lens alignment button (4) with the lens release button (2) on the camera body.
3. Fit the lens in this position, ensuring that it is perpendicular to the front of the camera.
4. Turn the lens slightly to the right to latch it audibly and perceptibly into place.

62



Removing the lens

1. Hold the lens by the fixed ring (15)
2. Depress the lens release button (2) on the camera body
3. Turn the lens anticlockwise until the lens alignment button (4) lines up with the lens release button
4. Remove the lens, keeping it perpendicular to the camera body.

Note: When the camera is loaded with film, change the lens in the shade of your body, as direct sunlight may otherwise penetrate the shutter.



Design of the LEICA M lenses

The LEICA M lenses are equipped with a fixed ring with depth-of-field scale (15), a rotatable focusing ring (16) and an aperture setting ring (17).

63



Focusing ring

The focusing ring (16) shows the distance set and, in conjunction with the scale (15), the depth-of-field range. For details on focusing, see the "Rangefinder" section on page 72.

Aperture ring (17)

The aperture values are standardised worldwide. They are selected such that the amount of light reaching the film is always halved when the lens is stopped down between two successive apertures (stops). One stop corresponds to one value on the shutter speed dial (10).

Like the shutter speed dial, the aperture ring engages perceptibly at each full stop (and for most lenses also at half-stops). With a little practice, you will also be able to set the apertures in the dark.

Like the shutter speed dial, the aperture ring moves in the same direction as the exposure meter displays in the viewfinder:

When the left triangular LED comes on, for example, turning the dial in the direction of the arrow, i.e. to the right, causes the slower shutter speed required to be set.

For further details on setting the correct exposure, see the "Exposure metering" section on page 74.



Depth-of-field scale

The plane which is rendered sharpest is the plane, parallel to the film, upon which the lens is focused. The optimum sharpness decreases progressively in front of and behind this plane such that a certain range exists within which the image is, to the eye, rendered sharply. This range is termed the depth of field. It is dependent on the focus setting, the focal length of the lens (the two values together determine the reproduction scale) and the aperture. Stopping down, i.e. selection of a larger f-number, increases depth-of-field, whilst widening the aperture, i.e. selection of a smaller f-number, decreases it. The depth-of-field scale in conjunction with the focusing ring indicates the range of sharpness at the set focus distance.

For example, using the LEICA SUMMILUX-M 50 mm f/1.4 lens focused at 5 metres, the depth-of-field at f/4 ranges from approximately 4 to 8 metres. Stopping down to f/11 at the same focusing distance, however, increases the range to 3 - 20 metres.



Lens hoods

Each LEICA M lens is supplied with a lens hood the design of which is geared to the lens. Several lenses have built-in telescopic lens hoods. The lens hoods should always be used as they provide both shade from stray light and glare and protection against rain drops or fingerprints.

Use of older LEICA M lenses

All LEICA M lenses can be used without restriction. However, the exposure metering system does not function with the following types:

- HOLOGON 15 mm f/8
- SUPER-ANGULON-M 21 mm f/4
- SUPER-ANGULON-M 21 mm f/3.4
- ELMARIT-M 28 mm f/2.8
- up to Serial No. 231 4921.

The following lens must be set to infinity during fitting/removal:

- SUMMICRON with close focusing 50 mm f/2



How to hold the camera correctly

In order to achieve sharp, well-focused photographs, the camera must be held as steadily and comfortably as possible. Hold the LEICA M6 TTL in a suitable, safe "three-point holding position" as follows: hold the camera with your right hand with your index finger on the release button and your thumb pushed behind the quick-wind lever in its operating, standby position. In addition, support the lens from below with your left hand, with which you can refocus quickly at any time, and press the camera against your forehead.



For vertical pictures, turn the LEICA M6 TTL to the left and keep your hands in the same position as for horizontal shots. You can however also rotate the camera to the right. In this case, it may be advantageous to release the shutter using your thumb.

Note: We recommend the practical handgrip M (accessory) to enable you to hold the LEICA M6 TTL and to carry it securely whilst keeping your hands free (order No. 14 405).

Bright-line viewfinder

The bright-line viewfinder of the LEICA M6 TTL comprises not only a high-quality, large, bright and high-contrast viewfinder showing every detail which will appear on the final picture, but also a highly accurate lens-coupled rangefinder.

The size of the frame corresponds to an image field of 23 x 35 mm (slide format) at the closest focusing distance for each lens. At longer distances, the image will contain a somewhat larger subject field than that shown within the bright-line frame.

The frames are coupled to the focusing mechanism such that parallax errors (the distance between lens and viewfinder axes) are automatically compensated for as the lens is focused, and the bright-line frame is the same as the film image in the entire range from 0.7m to ∞ .

There are three LEICA M6 TTL models with different versions of this viewfinder, which differ in their magnification:

When lenses with focal lengths of 28 (from serial No. 2411001 onwards), 35, 50, 75, 90 and 135 mm are used on the LEICA M6 TTL with 0.72x viewfinder magnification, the corresponding bright-line frame is automatically reflected

into the viewfinder in the combinations 28 + 90 mm, 35 + 135 mm and 50 + 75 mm.

When the LEICA M6 TTL is used with 0.85x viewfinder magnification, a corresponding five frames are reflected into the viewfinder for the focal lengths from 35 mm upwards (90 mm, 35 + 135 mm, 50 + 75 mm).


In the LEICA M6 TTL 0.58 five bright-line frames for the focal lengths as of 28 mm (28 + 90 mm, 35 mm, 50 + 75 mm) are projected into the viewfinder.

The centre of the viewfinder contains a somewhat brighter rectangle: this is the LEICA rangefinder. All lenses with focal lengths from 21 to 135 mm couple to the rangefinder when attached to the LEICA M6 TTL.

With the exposure meter switched on, the lower edge of the viewfinder also displays the LEDs of the exposure meter or the LED flash symbol.

For details on distance and exposure metering and flash operation, refer to the corresponding section on pages 72, 74 and 88.

68



69


Frame preselector

The frame preselector lever (18) extends the possibilities of the LEICA M6 TTL viewfinder. Using this integrated universal viewfinder, you can view frames which do not correspond to the lens which is actually fitted. Thus, you can test whether the composition would be better served by a different focal length.

When the lever is pointing outwards, i.e. away from the lens, the frames for the 35 and 135 mm focal lengths are displayed. The bright-line frame for the 135 mm focal length is not included in the viewfinder of the LEICA M6 TTL 0.58.

When the lever is in its vertical, central position, the frames for the 50 and 75 mm focal lengths are shown.


When the lever is pointing inwards, i.e. towards the lens, the LEICA M6 TTL viewfinder with 0.72x magnification displays the frames for the 28 and 90 mm focal lengths, and the 0.85x magnification viewfinder only shows the bright-line frame for the 90 mm focal length.



35 mm +
135 mm*




* not for LEICA M6 TTL 0.58



28 mm* +
90 mm



* not for LEICA M6 TTL 0.85



50 mm + 75 mm



Rangefinder

Thanks to its high effective base line value, the rangefinder of the three LEICA M6 TTL models permits very precise control. This is particularly advantageous when wide-angle lenses, which provide a relatively large depth-of-field, are used. The larger magnification of the 0.85-fold viewfinder with its longer base line leads to even higher accuracy:

	Mechanical base line (distance between the optical axes of the viewfinder and the rangefinder window)	x Viewfinder magnification	= Effective base line
LEICA M6 TTL with 0.72x viewfinder	69.25mm	x 0.72	Approx. = 49.9mm
LEICA M6 TTL with 0.85x viewfinder	69.25mm	x 0.85	Approx. = 58.9mm
LEICA M6 TTL with 0.58x viewfinder	69.25mm	x 0.58	Approx. = 40.2mm

The rangefinder field is the bright rectangle in the centre of the viewfinder field. If you cover up the large viewfinder window (14), only the bright-line frames and the rangefinder field remain visible. The bright, sharply defined rangefinder field permits the use of either coincidence or split-image rangefinder focusing.

Coincidence (double image) focusing


In most cases, and particularly for pictures of people, the coincidence or double-image method is preferable because it requires no straight lines in the subject. Simply cover the most important part of the subject with the rangefinder field, turn the focusing ring of the lens until the double image merges to one, and recompose (if necessary) to make the exposure.

Split-image focusing


For pictures of buildings or other subjects containing straight vertical lines, position the rangefinder field such that it is intersected by a line. Now turn the focusing ring of the lens until one continuous line is formed.

In practical use, it may be advantageous to combine both methods.


72




Double image = out of focus



Interrupted line = out of focus



Coincident image = in focus



Continuous line = in focus

73



Exposure metering

The LEICA M6 TTL meters for exposure under ambient light through the lens at the working aperture. The reading is selective, by light reflected from a bright metering field onto a photo diode (arrow). This diode is located behind a collecting lens to the left of and above the shutter. The metering field (diameter: 12 mm, i.e. approx. 13% of the negatives size) is situated in the centre of the first shutter curtain.

The unevenness of the white is not a result of poor manufacturing tolerances, but is due to the fact that a thick, complete coating cannot be applied to the rubberised cloth shutter curtain without the shutter performance being impaired. The irregular structure of the metering spot in no way affects the meter reading.

The lens f-stop and shutter speed for correct exposure are indicated by the appearance of the light balance (▶•◀) in the viewfinder: the exposure is correct when only the round LED in the middle comes on.

Switching on the exposure meter

The exposure meter is switched on by light pressure on the shutter release button (7), providing that the shutter is cocked and the shutter speed dial is not set to "B" or "OFF".

When one of the two triangular LEDs or the central round LED comes on, the exposure meter is ready for operation.

If finger pressure is released without the shutter being depressed, the exposure meter remains switched on for approx. 14s and the corresponding LED(s) remain on.

When the shutter is activated, the meter switches off and the LEDs in the viewfinder go out.

When the shutter is not cocked, or the shutter speed dial is set to "B" or "OFF", the exposure meter remains switched off.

Note: At very low levels of luminance, i.e. at the threshold of the light metering range, the LEDs may take approx. 0.5s to come on.

If the luminance levels fall below the working range of the exposure meter, the left-hand triangular LED flashes.

Setting shutter speed/lens aperture combinations for correct exposure

For correct exposure metering, the shutter must be cocked and the shutter speed dial must be set at a marked speed.

Then:

1. Switch on the exposure meter
2. Turn the shutter speed dial and/or the aperture ring on the lens in the direction indicated by the flashing LED until only the round LED comes on.

In addition to the direction of rotation of both shutter speed dial and lens aperture ring required for correct exposure, the three LEDs of the light balance also indicate over-, under- and correct exposure as follows:

- ▶ Underexposure by at least one f-stop; turn lens aperture ring clockwise.
- ▶• Underexposure by half an f-stop; turn lens aperture ring clockwise.
- Correct exposure
- ◀ Overexposure by half an f-stop; turn lens aperture ring anticlockwise.
- ◀ Overexposure by at least one f-stop; turn lens aperture ring anticlockwise.

Meter sensitivity

The light metering range begins at 0.03 cd/m^2 . The working range at ISO 100/21° extends from -2 to 20 EV (exposure value), i.e. from 4s (shutter speed dial position "B") at $f/1$ to $1/1000\text{s}$ at $f/32$ (see also diagram on page 79).

Very low light levels

Should the light level fall below the range of the exposure meter, the left triangular LED flashes.

Since the meter uses the working aperture, the LEDs may also flash when the lens is stopped down.

The exposure meter remains on for approximately 12 seconds after finger pressure is removed from the shutter release button, even if the light level is below the threshold sensitivity level. If the light level improves during this time (e.g. if the composition is changed or the aperture opened), the LEDs stop flashing and come on permanently.

General information on exposure metering

Most scenes contain an even distribution of bright and dark subject details and reflect an average of 18% of the light falling on them. This value of 18% corresponds to an average grey tone to which exposure meters are calibrated. Very bright subjects, such as snow-laden winter scenes, sandy beaches, whitewashed walls or a white wedding gown, reflect more light toward the exposure meter, tending to result in underexposure.

Predominantly dark subjects such as a black steam locomotive, dark grey slate roofs, and navy-blue uniforms reflect much less light, and meters tend to overexpose. To achieve correct exposures in these cases, the measured values must be corrected, unless exposure is measured selectively by inclusion of only a portion containing a representative sampling of dark and light subject details. You would for example meter on the bride's face and not on her white gown. A landscape shot with a wide-angle lens should be metered with the LEICA M6 TTL pointing downward to exclude the bright sky.

When no such metering alternative is available, a compensation factor of 2x or 4x can be used, the lens aperture can be opened by one or two f-stops, or the shutter speed increased.

often calls for an exposure increase of 4x, i.e. instead of the specified shutter speed of $1/1000\text{s}$ and $f/8$, use $1/250\text{s}$ and $f/8$ or $1/1000\text{s}$ and $f/4$. When photographing less bright subjects such as a sandy beach, a compensation factor of 2 is sufficient.

The reverse is the case for dark subjects. Note the tips below on exposure metering.

Switching off the exposure meter

If the camera is stored in a bag or left unused for some time, the shutter speed dial must be set to "OFF". This is valid even with released shutter. Only this setting switches off the light meter and the camera's circuitry.

Metering diagram

Data on the metering range of the exposure meter can be found on the right-hand side of the diagram.

Data on the working range of the focal-plane shutter and lenses can be seen on the left.

The exposure values (EV) are shown in the middle.

The metering range of the exposure meter is indicated on the right-hand side of the diagram, in cd/m^2 (candela per square metre).

The ISO film speed values (Sv) are shown at the top of the diagram.

The different exposure times in seconds (Tv = Time value) are shown on the left-hand side of the diagram.

The working range of the LEICA M6 TTL shutter is indicated schematically by the hatched vertical column at the far left-hand side of the drawing, "B" representing the unrestricted upper end.

The aperture values (Av) are shown on the lower left-hand side.

Example A shows the correlation between the film speed, luminance (brightness), exposure and aperture.

First follow the vertical line from the film speed (ISO 100/21°) down to the intersection on the horizontal line representing the corresponding luminance. In example A, this is 4000 cd/m², i.e. a typical value for bright sunlight. The line now runs diagonally to the vertical line indicating the aperture (11), and from there horizontally to the required exposure (1/250 s). In the course of this diagonal, the exposure value (15) can also be read off.

Example B shows that in candlelight and with a film speed of ISO 400/27° (1 cd/m²), photographs should be taken with an aperture of f/1.4 and a shutter speed of 1/15s. An aperture of f/11, for example, can no longer be used as the corresponding shutter speed of 4s is not available on the shutter speed dial. As the slowest shutter speed available on the dial is only 1s, exact metering is also no longer possible. The correct shutter speed can therefore be obtained only by conversion or from this diagram.


Metering fields

The metering field covers approx. 23% of the viewfinder image for the lens being used.





However, the following reference value applies to all lens focal lengths:

The diameter of the circular metering field is approx. 2/3 of the short side of the applicable bright-line frame. This also applies to lenses with viewfinder attachments, such as the LEICA ELMARIT-M 135 mm f/2.8





Metering diagram







LEICA M6 TTL
Viewfinder magnification 0.58







LEICA M6 TTL
Viewfinder magnification 0.58







LEICA M6 TTL
Viewfinder magnification 0.72



LEICA M6 TTL
Viewfinder magnification 0.72



LEICA M6 TTL
Viewfinder magnification 0.85



LEICA M6 TTL
Viewfinder magnification 0.85





Tips for exposure metering

Landscapes, close-ups or portraits, in the living room, at the airport or at parties - the majority of subjects contain many bright and dark details. Therefore, in general, exposure metering is not a problem. When the camera is tilted a little or turned to the left or right, the exposure value remains unchanged with selective metering. However, if a landscape scene containing many white clouds is photographed using a wide-angle lens or if the exposure meter is influenced by very bright lamps in a Bavarian beer tent, for example, the camera should be turned towards an area containing no particular bright or dark details.



To meter the exposure in the beer tent, the lens was pointed slightly downwards and to the left towards the lower left-hand corner of the picture to prevent the light source directly above the head of the person forming the subject from influencing the exposure reading.

In most cases, the photographer looks through the viewfinder whilst moving the camera in order to find the right framing - even for snapshots. The photographer can determine at the same time whether there is a sufficiently even distribution of dark and light details.






A easily identified detail in the frame is also necessary for focusing. If this detail does not happen to be in the centre of an interesting picture area, the camera again has to be moved; the dark/light distribution can of course be checked at the same time. The two pictures above were taken in this way.




Left: focusing and exposure metering on the boy on the right in the left-hand window - the camera is returned to the desired picture area - considerable change in exposure value, as the exposure meter now covers predominantly white details - move the camera therefore to the left and point the lens down for renewed exposure metering (metering field of the exposure meter is partially outside the subject area) - return to the original subject area - shoot.

84



On the bright beach of Acapulco the exposure value was determined by moving the camera to the right and metering outside the range of the subject area. The area which was metered contained reed huts, palm trees, deckchairs and people, i.e. an even distribution of light and dark details.

If such substitute measurements are not possible, exposure metering should be carried out on the light details, for example, the light sand on the beach or in the desert, the whitewashed walls in a Greek village or the snow on the run of a ski slope, and the value then corrected accordingly.



Opening the aperture by two stops corrects the exposure value for purely white details, as does multiplying the shutter speed by 4 (e.g. 1/125s instead of 1/500s). For light-coloured details such as sand, it is sufficient to open the aperture by one stop or double the shutter speed.

In sunny snowscapes the correct exposure for the areas of sunlight can be determined by metering in the shade. In this case no correction need be made.

For photographs of spotlight subjects, when many details of the subject are in the shadow, or for predominantly dark subjects such as steam engines or black fields of lava, small portions of the picture area with a good distribution of light and

85




dark details can usually be found which can be metered using spot metering.

In this picture taken at the ballet, the metered area was at the far right, partly outside the picture area. If suitable areas are not available, the dark details must be metered and a correction made, resulting in a smaller aperture or faster shutter speed. Stopping down by half a stop (in extreme cases a whole stop) is sufficient.



If there is considerable contrast between light and dark parts of the image, the exposure latitude of the films ceases to be sufficient to register the full tonal range of the subject in both the "light" and the "shade". The photographer must decide where he wishes to retain the greatest detail. For example, a person can appear as a black silhouette (underexposed) in front of a correctly exposed landscape, or correctly exposed in front of a "burnt-out" background (overexposed). A reading from "light" and "shadow" and the resulting average exposure usually leads to unsatisfactory results because delicate differences in brightness are lost in both the light and the dark areas.



The landscape shot was taken following metering in the lower right-hand part of the picture (shadow of the tree on the grass and the horse). For fast-moving subjects, there is often no time for exposure metering. In such cases, exposure metering is performed in advance. In this example, the top left-hand corner was metered, as the tape bordering the racetrack provided light and dark details.




Deliberate over- or underexposure often enhances the character of a picture and can be used as a good compositional aid. In this landscape shot, the fir trees and mountain ridges on the left of the picture (without the sky) were metered for the exposure, and the value was then reduced by two stops.



Use of flash

In addition to the photocell for ambient light, the LEICA M6 TTL is equipped with a second photocell for flash (arrow). This silicon photocell, located on the right below the shutter, enables the camera to measure the light emitted by the flash through the lens, at the working aperture. Through-the-lens metering on the LEICA M6 TTL is centre weighted and integral.

The camera can only control the flash light itself if flash units are used which are compatible with SCA 3000 and have an SCA 3501 adapter, or if the LEICA SF20 flash unit (order No. 14414) is mounted on the camera. This flash was specially designed for the LEICA M6 TTL.



Important

In order to trigger and control the flash units connected by means of the accessory shoe or the coaxial contact (x), the LEICA M6 TTL must be loaded with batteries and the exposure meter must be switched on by lightly pressing the shutter release button.

88



Compatible flash units

Thanks to its compact dimensions and its dedicated design, the LEICA SF20 is particularly suitable for use with the LEICA M6 TTL. It is very simple to use, as it is equipped with an integrated adapter foot with additional control and signal contacts for automatic transfer of a range of data and settings. In addition, it features a number of additional functions of interest.

However, the photographer can also fit any other proprietary flash unit, provided they are equipped with standard sockets, and also on-camera flash units with standardised adapter foot. These flash units are fired via the centre contact (x,11). We recommend the use of modern thyristor-controlled electronic flash units.

Fitting and connecting the flash unit

When mounting a flash unit on the hotshoe of the LEICA M6 TTL, ensure that the adapter foot of the flash unit is fully inserted and firmly secured by means of the tightening nut, if available. This is especially important in the case of flash units with additional control and signal contacts, as movements of the flash unit within the adapter foot may lead to the contact being broken and consequently to malfunctions.

The coaxial contact (x,22) for connecting flash units with cable connection is located below the accessory shoe at the back of the camera.

Note: The camera and flash unit must both be switched off before the flash is fitted.

89

TTL flash mode

This mode is available with the LEICA SF 20 and any other SCA 3000 flash unit equipped with the SCA adapter 3501. As soon as the requisite quantity of light has been emitted, the camera electronics of the LEICA M6 TTL transmit a "stop" signal to the flash unit, which immediately interrupts light output. This flash mode offers the advantage that all factors influencing exposure of the film (e.g. filters and aperture changes) are automatically taken into account.

In addition, the LEICA M6 TTL transfers the film speed set on the camera to the flash unit.

Flash units equipped with the corresponding displays can thus automatically adjust their range settings. The film speed setting cannot be influenced by means of the flash unit.

Settings for the TTL flash mode

After switching on the flash unit and setting it to "TTL", proceed as follows:

1. Turn the shutter speed dial of the LEICA M6 TTL to the flash synchronising speed "⚡" (1/50s) or select a slower shutter speed (or "B") for special effects.

2. Set the desired aperture or that required for the subject-to-camera distance.
3. Prior to any flash exposure, switch on the exposure meter by lightly pressing the shutter release button. If the release button is pressed down completely and the exposure meter remains switched off, the flash unit may not be fired.

Note: Since the aperture selected on the LEICA M6 TTL is not transferred to the flash, it must be set manually on the flash unit to enable the range to be read off on the latter, if the flash has such a display.

Flash exposure displays in the viewfinder in TTL and automatic flash mode with the flash unit SF 20 or flash units equipped with the SCA 3501 adapter

In the viewfinder of the LEICA M6 TTL, an LED in the shape of a flash (B) indicates the different modes:

- ⚡ is not displayed even though the flash is switched on:
The shutter speed set on the camera is faster than 1/50s
- ⚡ flashes slowly (at 2Hz) before the shutter is released:
The flash unit is not yet operational.
- ⚡ flashes before the exposure
The flash is operational.
- ⚡ continues to flash after the exposure:
Flash exposure was correct, flash remains operational.
- ⚡ flashes rapidly after the exposure (at 4Hz)
Flash exposure was correct, but flash is recycling.
- ⚡ does not flash following the exposure:
Underexposure, for example due to an aperture too small for the subject

Flash exposure displays in the viewfinder in manual flash mode

- ⚡ is not displayed even though the flash is switched on:
The shutter speed set on the camera is faster than 1/50s
- ⚡ flashes slowly (at 2Hz) before the shutter is released:
The flash unit is not yet operational.
- ⚡ flashes before the exposure
The flash is operational.

Flash exposure displays in the viewfinder in stroboscope flash mode

- ⚡ is not displayed even though the flash is switched on:
The shutter speed set on the camera is too fast for the number of flashes set on the flash unit
- ⚡ flashes slowly (at 2Hz) before the shutter is released:
The flash unit is not yet operational.
- ⚡ flashes before the exposure:
The flash is operational.

Note: For details on flash operation, particularly with other, non-TTL-compatible flash units, and information on the different modes of the flash units, refer to the instruction sheet of your flash unit.

System accessories for the LEICA M6 TTL

Interchangeable lenses

The LEICA M system is ideal for fast and candid photography. The range of lenses comprises focal lengths from 21 to 135 mm and widest apertures of f/1.

Filters

In black and white photography, filters are used for controlled rendition of tonal values, for example in order to achieve a natural reproduction of different colours in grey tones, or in order to improve the appearance of the sky or clouds on the picture. In colour photography, filters can be used to adjust colour rendition to the wishes of the user or to the spectral sensitivity of the film employed.

A range of different filters, equipped with standard filter thread sizes, are available for the current LEICA M lenses, including a universal polarising filter.

When the exposure is metered through the lens, any reduction in the quantity of light by the filter is automatically taken into account. However, films have different sensitivities in the individual spectral ranges; consequently denser, more ex-

treme filters may cause deviations from the correct exposure. For example, orange filters generally require one stop more exposure; red on average two stops more. A universally valid correction factor is not possible as the red sensitivity of black and white films varies considerably.

Eyesight correction lenses

For optimal matching of the viewfinder to the eye, correction lenses in the following strengths are available (dioptries, spherical): 0.5/1.5/2/3.

92

LEICA MOTOR M

The LEICA MOTOR-M can be attached to the LEICA M6 TTL and allows automatic shutter cocking and film advancing for single shots or series at rates of either up to 1.5fps or 3fps. The winder is mounted on the camera in place of the base plate, and is suitable for all shutter speeds from 1 to 1/1000s, including B. When the winder is switched off or if the batteries are dead, the film can still be wound on manually as normal. Remote release is possible via the cable release connection.



Bags and cases

For the LEICA M6 TTL with lenses from 21 to 50mm (except M 50mm f/1) an ever ready case with a detachable small front is available. For larger lenses (e.g. NOCTILUX-M/TRI-ELMAR-M) and for lenses from 21 to 50mm with hood attached an ever ready case with a large front is available. In addition, the classic combination bag is available for a camera plus up to three lenses, and the hold-all bag accommodates a camera with up to five lenses.

For LEICA M equipment, the small, elegant and weatherproof "Outdoor" bag is also available (see Handbook of the LEICA system).

93

Tips to ensure the lasting value of your Leica camera and lenses

If your Leica is to be stored for a longer period of time, please remove the batteries and make sure that the camera as well as the accessories are kept in a dry, well ventilated place. Photo cases that have gotten wet during use should be emptied, since the humidity and the release of leather-tanning agents may damage the equipment. To prevent fungal growth during use in hot humid tropical climates, the camera equipment should be exposed to as much ventilation as possible. Storage in airtight containers or cases can only be recommended when a drying substance such as Silicagel is used additionally. Since any dirt is also a breeding ground for micro-organisms, the equipment should carefully be kept clean.

All the mechanical operated bearing and gliding surfaces on your Leica have been lubricated. Please remember this when the camera is not in use for a longer period of time. To prevent the grease from becoming tacky, the camera shutter should be wound and released several times with each shutter speed. This should occur around every three months without film loaded. It is also recommended to move and use all the other operating elements (e.g. R-program selector, or M-image field selector). The lens helix (range setting) and aperture setting rings should also

be moved from time to time.

A lens works like a burning glass when bright sunlight shines on the front of the camera. This is why the camera should never be laid aside without first being protected against strong sunlight. Damage to the interior of the camera can be prevented by using the lens cover and keeping the camera in the shade (or directly in the case).

To remove stains and fingerprints, the camera and lens are wiped with a clean, lint-free cloth. We recommend microfiber cloths, that are stored in a protective container. They can be washed in temperatures up to 40 °C (without fabric softener, never iron!).

Rougher dirt in hard-to-reach corners of the camera body can be removed with a small brush. Please do not use any liquid cleaning agents to clean the camera body. Dust and lint of the inside of the camera (e.g. on the mirror or film track) are best removed carefully with a soft-hair brush that has been lubricated repeatedly with ether and then dried. Be careful not to damage the R-focusing screen with the shaft of the brush. Normally a soft-hair brush is sufficient for the removal of dust from the outer lens elements. In case of more stubborn dirt, a very clean, soft cloth that is completely free of foreign matter can be used, wiping carefully in cir-

cular motion from the inside to the outside. Eyeglass cleaning cloths, that are impregnated with chemicals, should not be used since they may damage the lens elements.

Optimum front-lens protection under unfavorable conditions (for example sand, salt-water-spray) can be achieved with colorless Uva filters. These can, however, as with any filter, cause undesirable reflections in certain backlight situations and with large contrasts. It is recommended to use the lens hood since it also protects the lens from fingerprints and rain.

Note the fabrication numbers of your camera (engraved on the bottom plate of your LEICA R, on the accessory shoe of your LEICA M) and lenses since these are extremely important in case of loss.

Alphabetical index

	Page		Page
Aperture setting ring	64	Lens hoods	66
Bags and cases	93	M lenses	62
Battery	55	- Design	63
Bright-line viewfinder	68	- Use of older lenses	66
Carrying strap	54	Metering diagram	77/79
Customer service	99	Metering fields	80
Depth-of-field scale	65	MOTOR M	93
Exposure meter	74	Quick-wind lever	57
- General information on exposure	76	Rangefinder	72
- metering	74	Shutter/aperture combination	75
- Switching on	74	Shutter release button	57
- Sensitivity	76	Shutter speed dial	97
- Switching off	77	Technical data	94
- Tips	82	Tips on maintenance of camera and lenses	90
- Very low light levels	76	TTL flash mode	94
Eyesight correction lenses	92		
Film	58		
- Loading	59		
- Film speed	60		
- Rewinding and removing	61		
Filters	92		
Flash operation	88		
Flash synchronisation	90		
Focusing ring	64		
Frame preselector lever	70		
Handgrip M	67		
Holding the camera	67		
Interchangeable lenses	92		

Technical data

Camera type: 35 mm rangefinder camera for the 24 x 36 mm format; mechanical shutter and selective through-the-lens exposure metering of the ambient light, or centre-weighted integral metering of the flash light with compatible flash units.

Lens mount: LEICA M bayonet

Lenses: 15 LEICA M lenses with focal lengths from 21 to 135 mm

Bright-line viewfinder: The subject is not viewed through the camera lens

Viewfinder magnification: 0.72x, 0.85x or 0.58x for all lenses

Viewfinder eyepiece: Adjusted for -0.5 dioptres, provision for screw-in correction lenses

Viewfinder display: Six (five in the 0.85x and 0.58x viewfinders) bright-line frames for the various focal lengths; rangefinding field; 3 LEDs for shutter/aperture balance, 1 LED for flash operation

Framing: By projection of pairs of bright-line frames into viewfinder: 28 and 90 mm (single 90/35 mm bright-line frame in the 0.85x / 0.58x viewfinder), or 35 and 135 mm, or 50 and 75 mm; automatic selection of correct frame for lens in use

Frame preselector: A three-position lever adjacent to the lens bayonet permits projection of two pairs of bright-line frames (single 90/35 mm bright-line frame in the 0.85x / 0.58x viewfinder) without the lens needing to be changed

Parallax compensation: Automatic compensation of horizontal and vertical viewfinder/lens parallax, coupled to focusing drive; the bright-line viewfinder frame automatically frames the subject to match the image in the lens

Identical image in viewfinder and on film: The bright-line frame corresponds to a framed 35 x 23 mm close-up slide for each focal length. At infinity, the film frame covers slightly more than the bright-line frame.

Wide-base rangefinder: Bright-field split-image and double-image rangefinder in centre of viewfinder image.

Effective base line: 49.9 mm (in the 0.72x viewfinder; mechanical base line 69.25 mm x viewfinder magnification 0.72x), 58.9 mm (in the 0.85x viewfinder; mechanical base line 69.25 mm x viewfinder magnification 0.85x) or 40.2 mm (in the

0.58x viewfinder; mechanical base line 69.25 mm x viewfinder magnification 0.58x).

Partly silvered viewfinder window: To improve visibility of the LEDs against a bright subject background, the lower and upper edge of the viewfinder window is silvered.

Exposure metering method: Selective through-the-lens metering at working aperture; centre-weighted integral TTL metering of the flash light at working aperture when compatible flash units are used.

Exposure metering principle: Measurement of light reflected by 12 mm diameter white circular dot in centre of first shutter curtain; area approx. 13% of negative size.

Orientation of exposure metering field in the viewfinder: Field diameter about 2/3 length of shorter side of viewfinder frame.

Photocell: Silicon photodiode behind condenser lens top left (for ambient light) and bottom right behind bayonet fitting of camera.

Spectral range: Modified by filters in front of photocell to match typical spectral range of human eye.

Sensitivity of exposure range: 0.03 cd/m² to 125 000 cd/m² at f/1

Low-light warning: By means of flashing triangular LED on the left in the viewfinder.

Working range: At ISO 100/21°, exposure values from -2 to 20 EV, i.e. 4s at f/1 ("B" setting) to 1/1000s at f/32.

Switching on the exposure meter: By light pressure on shutter release when shutter is cocked. Following the exposure, or with the shutter speed set to "B" or "OFF", the exposure meter is switched off after approx. 12s.

Exposure meter display: By light balance in the viewfinder with three red LEDs; the two triangular LEDs indicate the direction of rotation of aperture ring and shutter speed dial required for the shutter/aperture balance; in the event of under- or overexposure of at least 1 EV, one of the two triangular LEDs flashes; in the event of under- or overexposure of up to approx. 1/2 EV, one of the two triangular LEDs as well as the round LED in the centre flash; when shutter and aperture match the exposure meter, i.e. when selected exposure is correct, only the round LED in the centre comes on.

Aperture settings: By ring on front of lens, clickstops at full and half-stop settings.

Shutter settings: Large, easily accessible shutter speed dial on top plate of camera; also serves as main switch. Click-stop settings, can be read from above: OFF, B, 1 to 1/1000s and $\frac{1}{2}$ (=1/50s, flash sync speed, i.e. fastest shutter speed for flash operation); intermediate settings not possible.

Setting the correct shutter/aperture combination: Switch on exposure meter. Turn shutter speed dial and/or aperture ring until the central round LED (for precise exposure) or the central round LED and one of the triangular LEDs (for exposure with $\pm 2EV$) in the viewfinder come on; only one of the triangular LEDs flashing indicates over- or underexposure together with the required direction of rotation of the aperture ring and shutter speed dial.

Film speed: ISO 6/9° to ISO 6400/39°; ISO 12/12° to ISO 3200/36° for TTL mode

Power supply to exposure meter: Two silver oxide button cells, IEC type SR44 (diameter 11.6 mm, height 5.4 mm) or one 1/3 N lithium battery (diameter 11.6, height 10.8 mm).

Automatic battery check: If battery voltage is inadequate for accurate exposure metering, the right LED flashes.

Battery life: At an ambient temperature of 20°C and with the camera continuously switched on (shutter release button pressed), one set of fresh batteries lasts approx. 8 hours; at 10s per reading, this suffices for approx. 2900 exposures (approx. 80 films of 36 exposures each).

Shutter: Rubberised-cloth horizontal focal-plane shutter. Mechanically controlled speeds from 1s to 1/1000s, in full values. B for time exposures of any duration and $\frac{1}{2}$ (=1/50s) for flash operation. Extremely low-noise operation.

Flash sockets: Standard accessory shoe with centre contact and additional contacts for TTL flash control by the camera of compatible flash units (SCA 3000 standard or with SCA 3501 adapter); standard socket (X) for flashbulbs and electronic flash on the back of the camera; the two contacts can be used simultaneously.

Shutter release: Shutter release button with standard thread for cable release; gentle pressure on the button activates the exposure meter (light balance in the viewfinder).

Film transport: Angled quick-wind lever with movable handle; 120° movement transports film and cocks shutter, interval winding possible; "ready" position also suitable for left-eye viewing. Motorised film transport with add-on LEICA MOTOR M.

Frame counter: With magnifying display in top plate of camera; counts forward from -2 to 36, resets automatically on removal of base plate.

Rewind lever: Lever for rewind release on the front of the camera; sloped hinge-out rewind crank on the left-hand side of the camera top plate.

Camera body: Enclosed die-cast aluminium camera, detachable base plate. Top plate: 0.8 mm die-cast zinc; frame selector adjacent to lens mount. Eyelets on side of camera body for carrying strap; tripod thread - A /, DIN 4503; mechanical contact for LEICA MOTOR M; all three LEICA M6 TTL versions in black or silver chrome finish; LEICA M6 TTL 0.85 in black chrome.

Dimensions and weight (without lens, including batteries): 138 mm (height) x 79.5 mm (width) x 38 mm (depth), 600g.

Other LEICA products

Projectors

For your LEICA M6 slides, there is a comprehensive range of versatile, easy-to-use projectors, with a large choice of options for your LEICA M6 slides. The professional PRADOVIT-RT versions with round trays and the PRADOVIT P150, PRADOVIT P300 and PRADOVIT P600 offer total user convenience and a versatile range of optional modules. Superb optical performance in combination with traditional Leica precision mechanics are the common denominator of all LEICA projectors and projection lenses.

Binoculars and spotting scopes

Superb optics are the most outstanding single feature of all TRINOVID binoculars and TELEVID spotting scopes. They are made of the same high-grade optical glass as the world-famous LEICA lenses. Their excellent optical performance, exceptional resolution and superb brightness ensure a vivid three-dimensional image even in poor light.

Customer Service

For service and repairs or in the event of damage, please contact one of the LEICA representations abroad for assistance (see warranty card for address list). Alternatively, consult your authorised Leica Camera dealer.